

# **SW3000/02 - Estate Swing Stainless Steel Keypad (EASYKA) or (EASYBKA)**

1. Connect **Gray** wire from the keypad to **Terminal CYCLE CLOSE**.
2. Connect **Purple** wire from the keypad to **Terminal COMMON**.
3. Connect **Red** wire from the keypad to **Battery + (positive terminal)**.
4. Connect **Black** wire from the keypad to **Battery - (negative terminal)**.
5. The rest of the wires are used in more complex situations where the user is wishing to do more than simply control entering and exiting by code.

# SIMPLE ENTRY CODE PROGRAMING- Estate Swing Stainless Steel Keypad (EASYKA) or (EASYBKA)

#

Press in rapid succession

#

Light will turn from **green** to **red**

---

1

2

Enter default master code—this code does not open the gate ever and is not necessary to change

3

Light will go from **red** to **green**

4

---

7

Light will turn from **green** to **orange**

---

0

Enter the user slot number, you can have up to 500 users. Slot numbers go from '001' to '500'

0

A second light will flash **green**

1

---

?

?

Enter a four digit user code of your choice.  
Example '1538'

?

The second light will turn from **flashing green** to **solid green**

?

---

#

Press in rapid succession

#

**Orange** light will go out, **green** will stay on.

**Diagnostic Note:** If light flashes red, slot already has a code. Press '##' to exit and restart process with a different slot number or follow instructions to delete a slot code.