

APOLLO 3500/3600 - GateCrafters Outdoor Buried Driveway Exit Sensor *all lengths* (CS-200-S)**

1. Connect **RED** wire from the wand to **Terminal 12V** on one of the 3 pin terminal strips.
2. Connect **BROWN** wire from the wand to **Terminal 10 FREE EXIT**.
3. Connect **BLACK** wire from the wand to **Terminal GND** on one of the 3 pin terminal strips.
4. Connect **GREEN** from the wand to **Terminal 9 GND**.
5. Bury the exit wand approximately 1 foot underground parallel to the driveway.
6. DO NOT move the exit wand or bring metal near the exit wand for **5** minutes. During this time the wand is calibrating.

The white wire is not used.