

# **APOLLO 3500/3600 - GTO Automatic Exit Sensor *all lengths* (FM139,140,141)**

1. Connect **YELLOW** wire from the wand to the **YELLOW** wire of the **POT** (small board included with the exit wand).
2. Connect **BLACK** wire from the **POT** (small board included with the exit wand) to **Terminal GND** on one of the 3 pin terminal strips.
3. Connect **RED** wire from the wand to **Terminal 12V** on one of the 3 pin terminal strips.
4. Connect **BLUE** wire from the wand to **Terminal 10 FREE EXIT**.
5. Connect **BLACK** wire from the wand to **Terminal 9 GND**.
6. Connect **SHEILD** from the wand to **Terminal GND** on one of the 3 pin terminal strips (**the shield is the wire mesh directly under the outside casing, strip back the casing to revel the shield and twist the shield into one small stander to insert into the terminal**).
7. Bury the exit wand approximately 1 foot underground parallel to the driveway.
8. DO NOT move the exit wand or bring metal near the exit wand for **5** minutes. During this time the wand is calibrating.