

# **APOLLO 3500/3600 - NIR Retro-Reflective Photoeye (NIR)**

## **\*AS A SAFETY DEVICE\***

### ***Version Victory PB1200***

1. Connect **BLACK** wire from the NIR to **Terminal 14 SAFETY**.
2. Connect **WHITE** wire on the NIR to **Terminal 13 GND**.
3. Connect **Brown** wire on the NIR to **Terminal GND** on one of the 3 pin terminal strips .
4. Connect **BLUE** wire on the NIR to **Terminal 12V** on one of the 3 pin terminal strips .

**GREY** wire is not used.

# **APOLLO 3500/3600 - NIR Retro-Reflective Photoeye (NIR)**

## **\*AS AN OPENING DEVICE\***

### ***Version Victory PB1200***

1. Connect **BLACK** wire on the NIR to **Terminal 10 FREE EXIT**.
2. Connect **WHITE** wire on the NIR to **Terminal 9 GND**.
3. Connect **Brown** wire on the NIR to **Terminal GND** on one of the 3 pin terminal strips .
4. Connect **BLUE** wire on the NIR to **Terminal 12V** on one of the 3 pin terminal strips .

**GRAY** wire is not used.