

APOLLO 1550/1650 - NIR Retro-Reflective Photoeye (NIR)

AS A SAFETY DEVICE

Version BEN Series

1. Connect **BLACK** wire from the NIR to **Terminal 14 SAFETY**.
2. Connect **WHITE** wire on the NIR to **Terminal 13 GND**.
3. Connect **Brown** wire on the NIR to **Terminal GND** on one of the 3 pin terminal strips .
4. Connect **BLUE** wire on the NIR to **Terminal 12V** on one of the 3 pin terminal strips .

GREY wire is not used.

APOLLO 1550/1650 - NIR Retro-Reflective Photoeye (NIR)

AS AN OPENING DEVICE

Version BEN Series

1. Connect **BLACK** wire on the NIR to **Terminal 10 FREE EXIT**.
2. Connect **WHITE** wire on the NIR to **Terminal 9 GND**.
3. Connect **Brown** wire on the NIR to **Terminal GND** on one of the 3 pin terminal strips .
4. Connect **BLUE** wire on the NIR to **Terminal 12V** on one of the 3 pin terminal strips .

GRAY wire is not used.