

# **E-SU2200/02 - Universal Garage Door Receiver (P294-K)**

1. Connect **YELLOW** from the receiver to **Terminal OPEN A** on the CN4 terminal block.
2. Connect **WHITE** from the receiver to **Terminal COM** on the CN4 terminal block.
3. Connect **RED** from the receiver to **Terminal 24V+** on the CN1 terminal block.
4. Connect **BLACK** from the receiver to **Terminal 24V-** on the CN1 terminal block.
5. For better reception hang the antenna wire outside the control box, be sure to seal the control box to where you run the wire out to ensure the box stays weatherproof.
6. Set the internal dipswitches to match your remotes and set the larger dipswitches to **24V** and **Continuous**.

***THE ORANGE WIRE IS NOT USED.***