

E-S1100/02 - GateCrafters Outdoor Buried Driveway Exit Sensor *all lengths* (CS-200-S)**

1. Detach the green terminal strip from the bottom of the board.
2. Connect **RED** wire from the wand to terminal **11**.
3. Connect **BROWN** wire from the wand to terminal **1**.
4. Connect **BLACK** wire from the wand to terminal **13**.
5. Connect **GREEN** from the wand to terminal **12**.
6. Bury the exit wand approximately 1 foot underground parallel to the driveway.
7. Reconnect the terminal strip to the board and DO NOT move the exit wand or bring metal near the exit wand for **5** minutes. During this time the wand is calibrating.
8. Set the "A" parameter to "1".

The white wire is not used.