

E-S1100/02 - GTO Digital Keypad (F310) WIRED USE

1. Connect **LEFT RELAY OUTPUT** from the keypad to **Terminal 1** on the terminal strip.
2. Connect **RIGHT RELAY OUTPUT** from the keypad to **Terminal 12** on the terminal strip.
3. (OPTIONAL) Connect **LEFT AC/DC POWER IN** from the keypad to **Terminal 11** on the terminal strip.
4. (OPTIONAL) Connect **RIGHT AC/DC POWER IN** from the keypad to **Terminal 13** on the terminal strip.
5. Set the jumper to **ON**.

