

E-S1100/02 - Universal Garage Door Receiver (P294-K)

1. Connect **YELLOW** from the receiver to **Terminal 1** on the terminal strip.
2. Connect **WHITE** from the receiver to **Terminal 12** on the terminal strip.
3. Connect **RED** from the receiver to **Terminal 11** on the terminal strip.
4. Connect **BLACK** from the receiver to **Terminal 13** on the terminal strip.
5. For better reception hang the antenna wire outside the control box, be sure to seal the control box to where you run the wire out to ensure the box stays weatherproof.
6. Set the internal dipswitches to match your remotes and set the larger dipswitches to **12V** and **Continuous**.

THE ORANGE WIRE IS NOT USED.