

E-SC1102 - GTO Automatic Gate Lock (FM144,142)

1. Connect provided **WHITE** wire to terminal **1** (far left) of the lock board (small board included with the lock) and to terminal **7** of the gate opener control board.
2. Connect provided **BLACK** wire to terminal **2** of the lock board and to the **negative** terminal of the battery (**black**)
3. Connect **BLACK** wire of the lock to terminal **3** of the lock board.
4. Connect **RED** wire of the lock to terminal **4** of the lock board.
5. Connect provided **RED** wire to terminal **5** of the lock board and to the **positive** terminal of the battery (**red**)

