

E-SC1600/02 - GateCrafters Outdoor Buried Driveway Exit Sensor *all lengths* (CS-200-S)**

1. Detach the CN1 terminal block for the control board.
2. Connect **RED** wire from the wand to **Terminal 24V+** on the terminal block CN1.
3. Connect **BROWN** wire from the wand to **Terminal OPEN A** on the terminal block CN4.
4. Connect **BLACK** wire from the wand to **Terminal 24V-** on the terminal block CN1.
5. Connect **GREEN** from the wand to **Terminal COM** on the terminal block CN4.
6. Bury the exit wand approximately 1 foot underground parallel to the driveway.
7. Reconnect the CH1 terminal block to the board and DO NOT move the exit wand or bring metal near the exit wand for **5** minutes. During this time the wand is calibrating.
8. Change your parameters to **C1, D0, E1**. They must be set this way to work with the exit wand properly.

The white wire is not used.