

E-SC1600/02 - GTO Digital Keypad (F310) WIRED USE

1. Connect **LEFT RELAY OUTPUT** from the keypad to **Terminal OPEN A** on the CN4 terminal block.
2. Connect **RIGHT RELAY OUTPUT** from the keypad to **Terminal COM** on the CN4 terminal block.
3. (OPTIONAL) Connect **LEFT AC/DC POWER IN** from the keypad to **Terminal 24V+** on the CN1 terminal block.
4. (OPTIONAL) Connect **RIGHT AC/DC POWER IN** from the keypad to **Terminal 24V-** on the CN1 terminal block.
5. Set the jumper to **ON**.

