

# **G450/02 - GateCrafters Outdoor Buried Driveway Exit Sensor *all lengths* (CS-200-S\*\*)**

1. Turn the power switch to OFF.
2. Connect **RED** wire from the wand to terminal **VB**
3. Connect **BROWN** wire from the wand to terminal **EXIT**.
4. Connect **BLACK** wire from the wand to one of the **COM** terminals .
5. Connect **GREEN** from the wand to one of the **COM** terminals .
6. Bury the exit wand approximately 1 foot underground parallel to the driveway.
7. Turn ON the power switch and DO NOT move the exit wand or bring metal near the exit wand for **5** minutes. During this time the wand is calibrating.

*The white wire is not used.*