

G450/02 - GTO Automatic Exit Sensor *all lengths* (FM139,140,141)

1. Turn the power switch to OFF.
2. Connect **YELLOW** wire from the wand to the **YELLOW** wire of the **POT** (small board included with the exit wand).
3. Connect **BLACK** wire from the **POT** (small board included with the exit wand) to one of the **COM** terminals.
4. Connect **RED** wire from the wand to terminal **VB**.
5. Connect **BLUE** wire from the wand to terminal **CYCLE**.
6. Connect **BLACK** wire from the wand to one of the **COM** terminals.
7. Connect **SHEILD** from the wand to one of the **COM** terminals (**the shield is the wire mesh directly under the outside casing, strip back the casing to revel the shield and twist the shield into one small stander to insert into the terminal**).
8. Bury the exit wand approximately 1 foot underground parallel to the driveway.
9. Turn the power switch ON and DO NOT move the exit wand or bring metal near the exit wand for **5** minutes. During this time the wand is calibrating.