

G750/02 - GTO Automatic Gate Lock (FM144,142)

1. Connect **WHITE** wire of the lock board the **NO** terminal on the **Relay Out** block.
2. Connect **BLACK** wire of the lock board terminal 2 to **Battery - (negative terminal)**.
3. Connect **BLACK** wire of the lock to terminal 3 of the lock board.
4. Connect **RED** wire of the lock to terminal 4 of the lock board.
5. Connect **RED** wire of the lock board terminal 5 to **Battery + (positive terminal)**

