

# **SW1500 - Linear Access 2 Channel Digital Keypad (AK-1)**

1. Connect **N.O. 1** on the J3 terminal strip from the keypad to **Terminal CYCLE**.
2. Connect **COMMON 2** on the J3 terminal **strip** from the keypad to **Terminal COM-MON**.
3. Connect **+ power1** on the J4 terminal **strip** from the keypad to **Terminal AUX OUT +**.
4. Connect **- power 2** on the J4 terminal **strip** from the keypad to **Terminal COM-MON**.