

SW1500 - GateCrafters Outdoor Buried Driveway Exit Sensor *all lengths* (CS-200-S)**

1. Turn the power switch to OFF.
2. Connect **RED** wire from the wand to **Terminal AUX OUT +**.
3. Connect **BROWN** wire from the wand to **Terminal EXIT**.
4. Connect **BLACK** wire from the wand to **Terminal COMMON**.
5. Connect **GREEN** from the wand to **Terminal COMMON**.
6. Bury the exit wand approximately 1 foot underground parallel to the driveway.
7. Turn the power switch to ON and DO NOT move the exit wand or bring metal near the exit wand for **5** minutes. During this time the wand is calibrating.

The white wire is not used.