

APOLLO 3500/3600 - SOS Siren Safety Sensor (SOS-YDT)

1. Connect one of the **SW1** terminals (doesn't matter which) on the SOS Sensor to **Terminal 10 FREE EXIT**.
2. Connect one of the **SW1** terminals (doesn't matter which) on the SOS Sensor to **Terminal 9 GND**.
3. Connect the **Power +** terminal on the SOS Sensor to **Terminal 12V** on one of the 3 pin terminal strips .
4. Connect the **Power -** terminal on the SOS Sensor to **Terminal GND** on one of the 3 pin terminal strips .

The **SW2** terminals are not used.