

APOLLO 1550/1650 - Long Range Receiver (ER294-1K)

1. Connect **YELLOW** from the receiver to **Terminal INP** on one of the 3 pin terminal strips.
2. Connect **WHITE** from the receiver to **Terminal GND** on one of the 3 pin terminal strips.
3. Connect **RED** from the receiver to **Terminal 12V** on one of the 3 pin terminal strips.
4. Connect **BLACK** from the receiver to **Terminal GND** on one of the 3 pin terminal strips.
5. For better reception hang the antenna wire outside the control box, be sure to seal the control box to where you run the wire out to ensure the box stays weatherproof.
6. Set the internal dipswitches to match your remotes and set the larger dipswitches to **12V** and **Continuous**.

THE ORANGE WIRE IS NOT USED.