

APOLLO 1550/1650 - GTO Digital Keypad (F310) WIRED USE

1. Connect **LEFT RELAY OUTPUT** from the keypad to **Terminal INP** on one of the 3 pin terminal strips.
2. Connect **RIGHT RELAY OUTPUT** from the keypad to **Terminal GND** on one of the 3 pin terminal strips.
3. (OPTIONAL) Connect **LEFT AC/DC POWER IN** from the keypad to **Terminal 12V** on one of the 3 pin terminal strips.
4. (OPTIONAL) Connect **RIGHT AC/DC POWER IN** from the keypad to **Terminal GND** on one of the 3 pin terminal strips.
5. Set the jumper to **ON**.

