

APOLLO 1550/1650 - Extended Range Antenna(LR318ANT)

1. Attach the coaxial antenna connector to the coaxial connector on the side of the control box.
2. Attach the coaxial connector of the control box to the extended range antenna.