

APOLLO 1550/1650 - GateCrafters Universal Keypad & Proximity Card Reader (PRX- 320)

1. Connect **GREEN** wire on the **6-PIN** connector from the keypad to **Terminal INP** on one of the 3 pin terminal strips.
2. Connect **PURPLE** wire on the **6-PIN** connector from the keypad to **Terminal GND** on one of the 3 pin terminal strips.
3. Connect **RED** wire on the **6-PIN** connector from the keypad to **Terminal 12V** on one of the 3 pin terminal strips.
4. Connect **BROWN** wire on the **6-PIN** connector from the keypad to **Terminal GND** on one of the 3 pin terminal strips.

The 8-PIN and 2-PIN connectors are used for advanced installations, mostly used in commercial settings and are not necessary for the regular usage of this unit.