

E-SU2200/02 - GTO Automatic Gate Lock (FM144,142)

1. Connect **BLACK** wire of the lock to the right hand terminal **ELS** on the gate opener control board terminal CN2.
2. Connect **RED** wire of the lock to the left hand terminal **ELS** on the gate opener control board terminal CN2.