

G750/02 - Diablo Controls Loop Detector (DSP-6LP) *AS A SAFETY DEVICE*

1. Connect **NO (RELAY)** on the loop detector to the terminal **VEHICLE LOOP**.
2. Connect **COM (RELAY)** on the loop detector to one of the **COM** terminals.
3. Connect **COM (POWER)** on the loop detector to one of the **COM** terminals.
4. Connect **PWR (POWER)** on the loop detector to terminal **VB**.
5. Connect your buried loop to the two **LOOP** terminals on the loop detector.

Terminal **NC** is not used.

G750/02 - Diablo Controls Loop Detector (DSP-6LP) *AS AN OPENING DEVICE*

1. Connect **NO (RELAY)** on the loop detector to terminal **EXIT**.
2. Connect **COM (RELAY)** on the loop detector to one of the **COM** terminals.
3. Connect **COM (POWER)** on the loop detector to one of the **COM** terminals.
4. Connect **PWR (POWER)** on the loop detector to terminal **VB**.
5. Connect your buried loop to the two **LOOP** terminals on the loop detector.

Terminal **NC** is not used.