E-SC1600/02 - SOS Siren Safety Sensor (SOS-YDT)

1. Connect one of the **SW1** terminals (doesn't matter which) on the SOS Sensor to **Terminal OPEN A** on terminal block CN4.
2. Connect one of the **SW1** terminals (doesn't matter which) on the SOS Sensor to **Terminal COM** on terminal block CN4.
3. Connect the **Power +** terminal on the SOS Sensor to **Terminal 24V+** on terminal block CN1.
4. Connect the **Power -** terminal on the SOS Sensor to **Terminal 24V-** on terminal block CN1.
5. Change your parameters to **C1, D0, E1**. They must be set this way to work with the SOS properly.

The **SW2** terminals are not used.